

## **Contents**


3	<b>Introduction</b>	25	PB1 - Pendulum
3	The Process Explained	26	BM1 - BlokMag
3	<b>Remarks</b>	<b>28</b>	<b>Wireless Programming</b>
4	<b>What's Included</b>	28	Unit Discovery
4	Standard Configuration	29	Accessing the Wireless Configuration Settings
4	Telescopic Pack	30	Changing the Channel
5	<b>Technical Information</b>	30	Changing the SSID, Passphrase & IP Address
5	X2 - Transmitter	<b>31</b>	<b>Fault Finding Guide</b>
5	S4 - Sensor	<b>31</b>	Transmitter and Repeater LED Key
6	B4 - Battery	31	Transmitter and Wired Repeater LED Indicator Table
6	R4 - Repeater	32	Wireless Repeater LED Indicator Table
7	P2 - Processor	32	WiFi PCB LED Key
8	M2 - Monitor	32	AV PCB LED Key
8	CS1 - Charging Station	32	AV PCB LED Indicator Table
<b>9</b>	<b>System Configuration</b>	33	Processor LED Key
<b>10</b>	<b>Installation</b>	33	Processor LED Indicator Table
10	Mount & Secure the Transmitter	34	Flow Chart Referencing Guide
11	Mount, Connect & Secure the Sensor	35	Fault Finding Flow Charts
11	Mount, Connect & Secure the Battery	44	Battery Schematic
12	Mount & Secure the Repeater/s	44	Charging Station Schematic
12	Connecting and Powering the Repeater/s	45	Processor Schematic
13	Position and Connect the Processor	46	Repeater Schematic
13	Mount, Connect & Secure the Monitor	46	Transmitter Schematic
13	Connecting the Charging Station		
14	<b>Battery Charging Instructions</b>		
14	<b>Operating Instruction</b>		
15	<b>Accessing &amp; Downloading Saved Data</b>		
15	Connecting to the Network		
16	Set up the Video Management Software		
19	Selecting the Storage Location		
20	Viewing & Downloading the Recordings		
21	Viewing & Downloading the Screenshots		
22	Logging Out & Disconnecting the Laptop		
22	Logging In		
23	<b>Accessories</b>		
23	Office Link		
24	VC4 - V-Cam		
24	VC4a - V-Cam (Audio)		
25	FS1 - Footswitch		

## **Introduction**

BlokCam ® is a wireless system that can be quickly and easily deployed to the hook block or boom tip of a crane. The sound and view from below the camera is then transmitted and received wirelessly via the antenna system to a screen in the cab. This allows the operator to see and hear the load and surroundings, giving an unobstructed, live, audio-visual feed of the critical areas that working in the blind would never allow.

## **The Process Explained**

1. The Battery provides power to the Transmitter and the Sensor. The Sensor captures the audio-visual feed and sends it to the transmitter. Each component is magnetically attached and tethered to the desired surface. The signal is transmitted through one or more repeaters depending on the required configuration.
2. The Repeater is a modular transceiver which can be powered over ethernet (POE), by the BlokCam ® Battery or an alternative 12-24Vdc supply. The Repeater receives the wireless signal from the transmitter and relays the data back to a Processor and Monitor. The quantity and position of the repeater/s vary depending on the required configuration.
3. The final Repeater will be connected to, and powered over ethernet by the Processor. The Processor can be powered by mains or a 9-36vdc supply. The processor decodes the data and transfers the image and audio onto the Monitor. The Processor also powers the Monitor.



## **Remarks**

1. Always adhere to the crane manufacturer's instructions.
2. BlokCam ® should be used to assist the operator's judgement, not replace it.
3. All aspects of installation, removal, charging, use and fault finding should only be carried out by trained and competent persons
4. Ensure BlokCam ® parts and components do not interfere with crane manufacturers and/or third-party components, parts and systems, moving or otherwise.
5. The hook block parts and components are magnetically mounted; prior to adverse weather conditions or in any situation where the hook block may come into contact with the crane and/or third-party components, moving or otherwise remove all components from the hook block.
6. Always ensure that lanyards are connected, and Quick Links are tightened. Consider that the hook block may change configuration, shape and size.
7. High powered magnets in use. Neodymium magnets are permanent and strong, use correct protective equipment to avoid trapping hazard.
8. Working at Height. If possible, installation work should be completed at ground level, prior to the crane erection and installation of the jib. For working at height, please refer to regional and site-specific regulations and guidelines and ensure installation team are competent and adequately trained.
9. In Wi-Fi networking, a point-to-point wireless bridge lets users wirelessly connect two or more locations together. This bridge connects two or more locations to share data across the network.
10. BlokCam ® transceivers operate within the 5GHz band. For best results ensure a direct line of sight between all wireless transceivers and antennas.
11. Frequency selection and transmit power may vary. Please refer to regional regulations, guidelines and authorities to ensure legal operation.
12. A competent person should carry out pre-use checks prior to the commencement of work. Pre-use check sheets are available online from [www.blokcaml.com](http://www.blokcaml.com)
13. Parts and components may differ from renders.
14. Manual subject to change without notice
15. Subject to Copyright

## **What's Included**

### **Standard Configuration**


- 1 x Rugged Case
- 1 x Transmitter
- 1 x Sensor
- 2 x Batteries
- 1 x Charging Station
- 1 x Repeater
- 1 x Blanking Plug - Input Socket - 12-24Vdc
- 1 x Processor
- 1 x Monitor
- 2 x Power Supply Unit (AC-DC)
- 2 x PSU Mains Lead (Region Specific)
- 1 x Power Lead - Monitor
- 1 x 3m HDMI Lead - Monitor
- 5 x Quick Links
- 6 x 3mm x 600mm Lanyards
- 1 x LAN Cable - 75m
- 1 x Power Cable - Battery to Transmitter/Repeater
- 3 x 90 Degree N-Type Connector
- 4 x 7 dBi Duck Bill Antenna
- 1 x Twin Suction Cup
- 2 x Ram Mount Arm - Double Socket Arm
- 1 x Ram Mount with U-Bolts
- 1 x Ram Mount with Strap Base
- 1 x Pre-use Check Sheet (Pad)

### **Telescopic Pack**

- 1 x Rugged Case
- 2 x Batteries
- 1 x Charging Station
- 1 x Repeater
- 1 x Blanking Plug - Input Socket - 12-24Vdc
- 1 x Blanking Plug - Socket - PoE LAN Port
- 1 x Power Supply Unit (AC-DC)
- 1 x PSU Mains Lead (Region Specific)
- 2 x Quick Links
- 2 x 3mm x 600mm Lanyards
- 1 x Power Cable - Battery to Transmitter/Repeater
- 2 x 90 Degree N-Type Connector
- 2 x 7 dBi Duck Bill Antenna
- 1 x Magnetic Ram Mount with 1.5" Ball
- 1 x Ram Mount Arm - Double Socket Arm
- 1 x Ram Mount with U-Bolts
- 1 x Ram Mount with Strap Base

## Technical Information

### X2 - Transmitter



1. LED - Power
2. LED - Data
3. LED's – Signal Strength 25% - 100%
4. Sensor Socket – Audio
5. Sensor Socket - Video
6. Input Socket – 12-24Vdc
7. Mounting Magnets
8. Quick Link Anchor Points
9. 7dBi Duck Bill Antenna
10. 90 Degree N-Type Connector
11. Antenna Ports

#### Technical Specifications

**Video compression:** H.264 (MPEG-4 Part 10/AVC) Baseline, Main and High Profiles Motion JPEG

**Resolution:** 1920x1200/1080

**Frame Rate:** 25/30 fps (50/60 Hz)

**Video streaming:** Multiple, individually configurable streams in H.264 and Motion JPEG

**Image settings:** Compression, colour, brightness, sharpness, contrast, white balance, exposure value, exposure control, exposure zones, local contrast, rotation, Corridor Format, text and image overlay, privacy mask, mirroring of images

**Audio streaming:** One-way

**Audio input:** External microphone input

**Transmission Frequency:** 5 GHz

**Transmit Power:** 19-25dBm

**Size and Weight:**

Height: 128mm (5.04 inches)

Width: 170mm (6.69 inches)

Depth: 71mm (2.8 inches)

Weight: 2100g (4.63 pounds)

**Casing:** Aluminium.

**Power:** 12-24Vdc

**Power Consumption:** Max 13.3 W

**Antenna Connector:** N-Type


**Storage:** One internal SD/SDHC/SDXC slot supporting memory card, 64Gb card included.

**Operating Conditions:** -20 °C to 60 °C (-4 °F to 140 °F)  
Humidity 10-85% RH (non-condensing)

**Storage Conditions:** -40 °C to 65 °C (-40 °F to 149 °F)

**IP Rating:** IP 67 (with external ports connected)

### S4 - Sensor



1. Video Sensor
2. Audio Sensor
3. Mounting Magnets
4. Quick Link Anchor Points
5. Notch - Orientation Indicator Plate
6. Cable Gland
7. Sprung Loaded Rotary Boss
8. Map - Orientation Guide
9. Plug - Video Sensor (not shown)
10. Plug - Audio Sensor (not shown)

#### Technical Specifications

**Video Sensor:** Fixed Iris, 1080p

**Resolutions:** Max1920x1200/1080

**Minimum illumination:** Colour: 0.3 lux

**Frame Rate:** Max 50/60 fps (50/60 Hz)

**Audio streaming:** One-way

**Audio input:** External microphone input

**Transmission Frequency:** 5 GHz

**Transmit Power:** 19-25dBm

**Size and Weight:**

Height: 100mm (3.94 inches)

Width: 75mm (2.95 inches)

Depth: 69mm (2.72 inches)

Weight: 1250g (2.76 pounds)

**Casing:** Aluminium.

**Power:** Provided by Transmitter


**Operating Conditions:** -20 °C to 55 °C (-4 °F to 131 °F)

Humidity up to 75% RH (non-condensing)

**Storage Conditions:** -20 °C to 60 °C (-4 °F to 140 °F)

**IP Rating:** IP 67 (with external ports connected, excludes IP65 Audio Sensor)

## B4 - Battery



1. Output Socket (Pin 1 - Negative, Pin 2 - Positive)
2. On/Off Toggle Switch (optional extras)
3. Quick Link Anchor Points
4. Viewing Windows - Socket and Switch
5. Recharge Docking Contact - Pin 1 (-) Negative
6. Recharge Docking Contact - Pin 2 (+) Positive
7. Recharge Docking Contact - Pin 3 (+) Thermistor
8. Recharge Docking Contact - Pin 4 (+) Charge station loop
9. Recharge Docking Contact - Pin 5 (+) Charge station loop
10. Mounting Magnets (not shown)

### Technical Specifications

**Capacity:** 19.2V 4.2Ah

**Cell Manufacturer:** Panasonic

**Cell Type:** Nickel-Metal Hydride Battery

**Nominal Cell Voltage:** 1.2V

**Internal Fuse:** 500mA

#### Size and Weight:

Height: 100mm (3.94 inches)

Width: 75mm (2.95 inches)


Depth: 69mm (2.72 inches)

Weight: 1250g (2.76 pounds)

**MSDS:** available from [www.blokcams.com](http://www.blokcams.com)

**IP Rating:** IP 67 (with external ports connected)

## R4 - Repeater



1. LED - Power
2. LED - Data
3. LED's - Signal Strength 25% - 100%
4. Socket - Blank
5. Socket - PoE LAN Port
6. Input Socket - 12-24Vdc
7. 1.5" Ball Joint (not shown)
8. Quick Link Anchor Points
9. 7dBi Duck Bill Antenna
10. 90 Degree N-Type Connector
11. Antenna Ports (not shown)

### Technical Specifications

**Transmission Frequency:** 5 GHz

**Transmit Power:** 19 to 25dBm

Receiver Sensitivity: -90 to -75 dBm

#### Size and Weight:

Height: 128mm (5.04 inches)

Width: 170mm (6.69 inches)

Depth: 58mm (2.28 inches)

Weight: 1800g (3.97 pounds)

**Casing:** Aluminium.

**Power:** 12-24Vdc, Passive PoE 24V

**Power Consumption:** Max 5.5 W

**Antenna Connector:** N-Type

**Operating Conditions:** -20 °C to 70 °C (-4 °F to 158 °F)




Humidity up to 5 to 95% (non-condensing)

**Storage Conditions:** -40 °C to 90 °C (-40 °F to 194 °F)

Humidity Max 90% (non-condensing)

**IP Rating:** IP 67 (with external ports connected)

## P2 - Processor



1. Input Socket - 9-36Vdc 5A
2. Input Socket - Colour Code - Red
3. Switch Socket - Multi Camera
4. Switch Socket - Colour Code - Blue
5. Output Socket - Monitor - 12Vdc 3.3A
6. Output Socket - Colour Code - Yellow
7. Output Socket - HDMI
8. POE Ports (Ports 1 - 4)
9. LAN Port (Ports 5 & 6)
10. LED - Power
11. LED - Data
12. LED - 1 - 6 Port related
13. Cable release port

## Technical Specifications

**Video Compression:** H.264

**Latency:** >150mS

**Frame Rate:** Max 60 fps

**Resolution:** 1920 x 1080

**Video and Audio Output:** HDMI

**Monitor Output:** 12Vdc 3.3A

**Size and Weight:**

Height: 121mm (4.76 inches)

Width: 190mm (7.48 inches)

Depth: 161mm (6.34 inches)

Weight: 3800g (8.38 pounds)

**Casing:** Aluminium.

**Power:** 9-36Vdc 5A

**Operating Conditions:** 0 °C to 40 °C (32 °F to 104 °F)


Humidity up to 10% to 90% (non-condensing)

**Storage Conditions:** -40 °C to 70 °C (-40 °F to 158 °F)

Humidity 5% to 90% (non-condensing)



## M2 - Monitor




1. Button - Power
2. Button - Input
3. Button - FN (Function)
4. Button - MENU/EXIT
5. Navigation Wheel
6. Input Socket - 12Vdc
7. Input Socket – HDMI
8. 4 x Threaded Holes for Vesa Mount with 1.5" Ball Joint
9. Vesa Mount with 1.5" Ball Joint (Not Shown)

### Technical Specifications

**Screen Size:** 10.1"  
**Aspect Ratio:** 16:9  
**Resolution (pixels):** 1920 x 1080  
**Scan Frequency (Hz):** 60-72  
**Response time (ms):** 20  
**Viewing Angle (degrees)** 170 x, 170 y  
**Brightness (cd/m²):** 350  
**Contrast Ratio:** 800:1  
**LCD backlight:** LED  
**Video and Audio Input:** HDMI  
**Audio Output:** <1.2W Speaker, 3.5mm Headphone Output  
**Size and Weight:**  
 Height: 121mm (4.76 inches)  
 Width: 190mm (7.48 inches)  
 Depth: 161mm (6.34 inches)  
 Weight: 3800g (8.38 pounds)  
**Casing:** Plastic  
**Power:** 12Vdc 3.3A - Provided by Processor  
**Operating Conditions:** -20 °C to 60 °C (-4 °F to 140 °F)

## CS1 - Charging Station



1. Input Socket - 10-30Vdc 4A
2. Input Socket - Colour Code - Red
3. LED – Charge indicator
4. Recharge Spring Contact - Pin 1 (-) Negative
5. Recharge Spring Contact - Pin 2 (+) Positive
6. Recharge Spring Contact - Pin 3 (+) Thermistor
7. Recharge Spring Contact - Pin 4 (+) Charge station feed
8. Recharge Spring Contact - Pin 5 (+) Charge station return
9. Charge Indicator Plate (on rear, not shown)

### Technical Specifications

**Power:** 10-30Vdc 4A  
**Size and Weight:**  
 Height: 96mm (3.78 inches)  
 Width: 150mm (5.9 inches)  
 Depth: 100mm (3.94 inches)  
 Weight: 2500g (5.51 pounds)  
**Casing:** Aluminium.  
**Internal Fuse:** 5A

### Charge Indicator Plate

Led	Mode	Output
Yellow	No battery	41v
Yellow	Initialization	50mA
Orange	Fast Charge	0.9A
Green/yellow	Top-off ch	130mA
Green	Trickle ch	50mA
Orange/Green	Error	50mA




## System Configuration

### Foreword


BlokCam ® X2 Crane Camera is a modular system. The required set up and installation are dependent on the machine and the environment.

The following characterise the most common crane installations


### Luffing



### Flat Top






### Telescopic



## **Installation**

### **Foreword**

Duck Bill Antennas are omni directional. For best performance, the orientation between the transmitting and receiving antennas must remain parallel and in-line (not offset), consistent and with a direct line of sight. Omni directional antennas do not emit a signal out of the tip of the antenna.



## **Mount & Secure the Transmitter**

Pre-empt the position of the Transmitter and consider:

a. lanyard length and distance to a secure point receiving Repeater and, whilst ensuring a direct line of sight to the anticipated Repeater position.

1. Magnetically mount the Transmitter to a clean and flat surface.
2. Connect 2 x N-type right angle connector onto the antenna ports.
3. Connect a 7dBi Antenna to each of the N-type right angle connectors.
4. Both Antenna's should be horizontally positioned and at a right angle to each other.
5. Once the optimum position has been achieved, firmly tighten the antenna's and N-type connectors.
6. Fit Quick Link to Transmitter anchor point.
7. Choke and secure a lanyard to a fixed and secure point.
8. Attach the loose end of Lanyard to the Quick Link.
9. Firmly tighten the Quick Link.

When necessary reverse the above steps for removal.


## Mount, Connect & Secure the Sensor


### Foreword

The installation and orientation of the camera must correctly correlate with the monitor and machinery movements. Following installation, test to ensure the relationship between the camera, monitor and machinery is accurate.

Pre-empt the position of the Sensor and consider:

- a. the sensor cable length and route;
  - b. the distance to the Transmitter;
  - c. the view from the intended position;
  - d. the lanyard length and distance to a secure point;
  - e. the orientation of the camera;
  - f. if a pendulum will be required to compensate for the dynamics of the machine.
1. Changing the orientation of the camera is a tool free operation. The Camera and Rotary Boss are sprung loaded into locator slots. To rotate the camera, lift, rotate and lower the Sprung Loaded Rotary Boss. Use the engraved text, map and notch as a guide to relocate correctly. As indicated the Rotary Boss will not rotate past 315 degrees due to the rotation stop.




2. Magnetically mount the Sensor to a clean and flat surface.
3. Connect Video Sensor Plug to the Video Sensor Socket on the underside of the Transmitter.
4. Connect Audio Sensor Plug to the Audio Sensor Socket  on the underside of the Transmitter.
5. Secure the cable to a clean and flat surface using the pre-installed cable magnets.
6. Fit Quick Link to Sensor anchor point.
7. Choke and secure a lanyard to a fixed and secure point.
8. Attach the loose end of lanyard to the Quick Link.
9. Firmly tighten the Quick Link.

When necessary reverse the above steps for removal.

## Mount, Connect & Secure the Battery

Pre-empt the position of the Battery and consider:

- a. the power cable length and route;
  - b. the distance between the Battery and Transmitter;
  - c. the lanyard length and distance to a secure point;
  - d. that the battery is changed on a regular basis.
1. Magnetically mount the Battery to a clean and flat surface.
  2. Connect the Power Cable between the Output socket on the Battery and the Input Socket  on the Transmitter.
  3. Secure the cable to a clean and flat surface using the pre-installed cable magnets.
  4. Fit Quick Link to Battery.
  5. Choke and secure a lanyard to fixed and secure point.
  6. Attach the loose end of lanyard to the Quick Link.
  7. Firmly tighten the Quick Link.

When necessary reverse the above steps for removal.

## Mount & Secure the Repeater/s

### Foreword

The Repeater is a modular transceiver that relays the wireless signal. The Repeater can be powered over ethernet (POE), by the BlokCam ® Battery or an alternative 12-24Vdc supply.


To protect against ingress, it is necessary to cap and seal all unused ports using the supplied blanking plug/s.

The installation, quantity, mounting, location, position and orientation are dependent on the required configuration.

Systems with multiple Repeaters must be connected in the correct series order.

The final Repeater in the series is connected to, and powered over ethernet by the Processor's POE Ports (Ports 1 – 4).

Always adhere to correct antenna alignment. Duck Bill Antennas are omni directional. For best performance, the orientation between the transmitting and receiving antennas must remain parallel and in-line (not offset), consistent and with a direct line of sight. Omni directional antennas do not emit a signal out of the tip of the antenna.



Pre-empt the position of the Repeater and consider:

- the data output method, wired or wireless;
  - the best suited power supply option;
  - the adjacent point to point relationship/s;
  - the antenna configuration;
  - mounting options;
  - the lanyard length and distance to a secure point;
  - which ports will need blanking;
  - the dynamics of machine.
1. Attach the best suited RAM Mount, Ball Joint Bracket to a fixed and secure point. If the supplied brackets are not suitable please seek advice from an authorised BlokCam ® dealer.
  2. Connect the Double Socket Ram Mount Arm complete with lanyard to the RAM Mount Ball Joint Bracket.
  3. Connect the Ball Joint attached to the rear of the Repeater to the Double Socket Ram Mount Arm.
  4. Fit Quick Link to Repeater.
  5. Connect Double Socket Arm lanyard to Quick Link.
  6. Choke and secure a second lanyard to fixed and secure point.

7. Attach the loose end of lanyard to the Quick Link.
8. Firmly tighten the Quick Link.
9. Connect 1 x N-type right angle connector onto an antenna port.
10. Connect a 7dBi Antenna to each of the ports.
11. Once the optimum point to point position has been achieved, firmly tighten the Ram Mount Brackets, Antenna's and N-type connector.

When necessary reverse the above steps for removal.

## Connecting & Powering the Repeater/s

### Wireless (battery powered)

1. Fit 1 x Lan Port Blanking Plug to the LAN Port Socket.
2. Mount, connect and secure the BlokCam ® Battery as instructed on page 11.

### Wireless (alternative 12-24Vdc supply)

1. Fit 1 x Lan Port Blanking Plug to the LAN Port Socket.
2. Obtain any required permissions to tap into a suitable supply.
3. Connect the supply to the 12-24Vdc Input Socket.

### Wired (powered over ethernet)

1. Fit 1 x Input Socket Blanking Plug to the 12-24v Input Socket.
2. Connect the Bayonet fitting from the '75m LAN Cable' to the LAN Port Socket on the Repeater.
3. Install and secure the cable from the Repeater to the anticipated Processor location using zip ties.

## Position & Connect the Processor

Pre-empt the position of the Processor and consider:

- a. the IP Rating, the Processor must be kept indoors;
- b. the type of power supply, AC or DC;
- c. the PSU/Power Cable, length and route;
- d. the 75m LAN Cable length and route;
- e. the monitor position;
- f. the distance to the Monitor.

Systems with additional accessories may require considerations for:

- a. connecting and positioning additional cameras;
  - b. connecting and positioning a footswitch;
  - c. connecting and positioning a joystick;
  - d. connecting and positioning additional Repeaters;
  - e. connecting a laptop.
1. Connect the 75m LAN Cable from the Repeater to one of the Processor's POE Ports (Ports 1 – 4).
  2. Connect the 3m HDMI Lead to the HDMI Socket
  3. Connect the Monitor's Power Lead to the Yellow Output Socket (12Vdc 3.3A).
  4.
    - a. Connect the AC-DC Power Supply Unit and associated PSU Mains Lead between the Red Input Socket and a mains supply socket.

or

    - b. Connect the DC-DC Power Supply Cable between the Red Input Socket and a suitable DC supply socket.
  6. Route and secure the Monitor's HDMI and Power Lead from the Processor to the anticipated Monitor location using zip ties.

When necessary reverse the above steps for removal.

## Mount, Connect & Secure the Monitor

Pre-empt the position of the monitor and consider:

- a. the mounting options;
  - b. the lanyard length and distance to a secure point;
  - c. the HDMI and power cable length and route.
1. Attach the best suited RAM Mount, Ball Joint Bracket to a fixed and secure point. If the supplied brackets are not suitable please seek advice from an authorised BlokCam ® dealer.
  2. Connect the Double Socket Ram Mount Arm complete with lanyard to the RAM Mount Ball Joint Bracket.
  3. Route the Double Socket Arm Lanyard to a fixed and secure point. If necessary, fit and firmly tighten a Quick Link to secure.
  4. Connect the Ball Joint attached to the rear of the Monitor to the Double Socket Ram Mount Arm.
  5. Connect the HDMI Cable to the HDMI Port.
  6. Connect the Power Cable to the 12Vdc Input Socket.
  7. Adjust the mounting system to achieve the desired position and firmly tighten the Ram Mount Brackets.

When necessary reverse the above steps for removal.

## Connecting the Charging Station

### Foreword

The charging station should be kept in a clean and dry environment.

1. Place the Charging Station on a clean, dry, flat and level surface. Ensure ease of access and egress and that the chosen position is within reach of a suitable power source.
2.
  - a. Connect the AC-DC Power Supply Unit and associated PSU Mains Lead between the Red Input Socket and a mains supply socket.

or

  - b. Connect the DC-DC Power Supply Cable between the Red Input Socket and a suitable DC supply socket.

When necessary reverse the above steps for removal.

## **Battery Charging Instructions**

### **Foreword**

The BlokCam ® X2 camera system runs on a non-hazardous battery. Under normal operating conditions each battery should provide approximately 12 hours of use. Certain operating conditions will decrease the standard runtime of the battery, including extreme hot or cold temperatures. The battery takes approximately 5 hours to fully charge.

Spare batteries should be kept in a clean and dry environment. BlokCam ® recommend swapping and charging the battery at the beginning of every shift.

1. Ensure charging contacts on the Battery and Charging Station are clean, dry and in good condition.
2. Ensure that the Charging Station is powered up.
3. Place the discharged battery into the Charging Station.



4. Use the Charge Indicator LED and Indicator Plate to monitor the charge condition.
5. When charged and/or required, lift the battery from the Charging Station.

## **Operating Instructions**

### **Foreword**

Operation is reliant on correct installation, charged batteries and/or reliable power source.

1. Power up the Processor.
2. The Monitor should power up automatically. If the Monitor does not power up automatically, press the power button on the right-hand side of the Monitor.
3. Wired Repeaters will power up automatically.
4. If applicable, power up any Wireless Repeater/s as instructed on page 12.
5. Power up the Transmitter. Mount, connect and secure a fully charged battery to the Transmitter as instructed on page 11.
6. Following completion of the start-up procedure the camera system should be fully functional and ready to use.
7. If required, re-position the sensor to achieve the desired view.

If you are experiencing difficulties, please refer to the fault finding guide.

## Accessing & Downloading Saved Data

### Foreword

To access and download saved data, ensure the BlokCam ® system and components are installed correctly and fully operational.

You will need a Laptop with VMS installed (Video Management Software), a Cat5e RJ45 Patch Cable of suitable length, basic networking and IT skills and access to the Processor. Laptop/System recommendations and VMS are available from [www.blokcaml.com](http://www.blokcaml.com)


### Connecting to the Network

1. Connect the Cat5e RJ45 Patch Cable between the laptop and LAN Port 5 or 6 on the processor.
2. To avoid conflict, ensure all other networks, wired or otherwise are disconnected and/or disabled.
3. Ensure the Laptop Internet Protocol Version 4 Properties are configured to 'Obtain an IP address automatically'.
4. Ensure the Laptop Internet Protocol Version 4 Properties are configured to 'Obtain DNS server address automatically'.

In some scenarios it may be necessary to manually configure the Laptops IP Address.

An IPv4 IP Address is made up of 4 Octets. The first, second and third Octet must be identical for connectivity across all paired units. The forth Octet must be unique to avoid conflicting IP Addresses.


IPv4	1 <sup>st</sup> Octet	2 <sup>nd</sup> Octet	3 <sup>rd</sup> Octet	4 <sup>th</sup> Octet
Laptop	192	168	0	189
Camera	192	168	0	191
Transmitter	192	168	0	192
1 <sup>st</sup> Repeater	192	168	0	193
2 <sup>nd</sup> Repeater	192	168	0	194
Office Link	192	168	0	195





## Set up the Video Management Software

1. Open the VMS application.
2. Select 'Create new site' or 'GET STARTED'.



or




3. Choose and type your preferred site name into the 'Site name' box.




4. Obtain the Site password from an authorised BlokCam ® dealer. Do not create a password. Creating a password will lead to system failure.

5. Type the procured password into the 'Site password' box.




6. Re-type the procured password into the 'Confirm password' box.



7. Select 'Next'.




8. The VMS will attempt to automatically search and discover all available network cameras. If the desired camera is discovered, skip to step 12.




9. If the desired camera is not automatically discovered, obtain the cameras IP Address from an authorised BlokCam® dealer and add the camera manually.


10. Type the procured IP Address into the 'Enter camera address' box.




11. Select the 'ADD' arrow to the right of the IP Address




12. Ensure the desired camera/s is/are selected.




13. Select 'Next'.




14. Wait until the VMS contacts the selected camera/s.



15. Select 'Finish' on the 'Ready to install' page.




16. Wait until the VMS installs the selected camera/s.




## Selecting the Storage Location


1. Locate 3 icons on the top left of the VMS software screen. Select 'Go to Configuration'.




2. Select 'Customize' on the 'Go to Configuration' Screen.




3. Under the heading 'Snapshot folder' locate and select 'Browse...'.




4. Select the desired storage location.



5. Select 'OK'.




6. Check the storage location has changed and select 'Open folder when snapshot is taken' box.




7. Repeat steps 3 – 6 for the 'Recordings' section.

## Viewing & Downloading the Recordings


1. Locate the 3 icons on the top left of the VMS software screen. Select 'Go to Recordings'.




2. Select the footage from the date required by scrolling through the dates using the arrows left and/or right of the date displayed.




3. Locate and select the 'Save Recordings' icon on the bottom right of the VMS screen.



4. The blue time line indicates the duration of recording on the selected date. Use the grey trimming arrows to reduce or increase the duration of the required interval. For speed and storage reasons, please keep the download duration to a minimum.




5. If required, select the yellow arrow. Then magnify the timeline using the + and/or - option/s.




6. If necessary, repeat and refine step 4.


7. When the required interval has been found, select 'Save'.



8. Wait whilst the selected recording interval is saved to the desired location.




9. When the recording interval is saved, the folder containing the file will open. Check the file is stored in the required location and close the folder using the 'X' at the top right of the 'Folder' page.




10. Repeat Steps 1 – 9 to extract more recording intervals if required.

## Viewing & Downloading the Screenshots


1. Access the 'Go to Recordings' screen. Locate the 3 icons on the top left of the VMS screen. Select 'Go to Recordings'.




2. Select the footage from the date required by scrolling through the dates using the arrows left and/or right of the date displayed.




3. Select and slide the yellow arrow to magnify, locate and refine your search.




4. Locate the required image and select the 'Investigation Mode' icon on the bottom right of the VMS screen.




5. Use the slide bar and thumbnail icons to skip and view the footage frame by frame.



6. Select the Camera icon to save the individual image/frame.




7. When the image is saved, the folder containing the file will open. Check the file is stored in the required location and close the folder using the 'X' at the top right of the 'Folder' page.



8. Repeat Steps 5 – 7 to extract more images if required.


9. Exit Investigation mode using the 'X' at the top right of the 'Investigation Mode' page.






## Logging Out & Disconnecting the Laptop


1. On the top right of the VMS software screen, locate and select the menu icon (the three horizontal bars).



2. On the drop-down menu select 'Log Out'.



3. Locate and select the 'X' at the top right of the VMS to close application.




4. Disconnect the Cat5e RJ45 Patch Cable from the Laptop.
5. The Processor is manufactured with an anti-tamper system. Insert a suitable tool (not supplied) into the cable release port, push the patch cable latch and simultaneously disconnect the Cat5e RJ45 Patch Cable from the Processor.

## Logging In


### Foreword

Logging in is only possible once the VMS has been set up as detailed on page 16.


1. Connect to the network as detailed on page 15.
2. Open the VMS application software.
3. Select the arrow to activate the drop-down menu and select the desired 'Camera site'.




4. Type the password into the 'Site password' box.



5. Select 'Remember password' box if required.




6. Select 'LOG IN'.





## **Accessories**

### **OL1 – Office Link**



2. Once the optimum point to point position has been achieved, firmly tighten the adjustable steel bracket.
3. Secure the cable from the Office Link to the anticipated Laptop location using zip ties.
4. Connect the cable to the output socket on the POE Injector.
5. Connect the Cat5e RJ45 Patch Cable between the POE Injector and the laptop.
6. Connect the POE Injector to a suitable mains supply socket.
7. Power up the POE Injector.
8. Power up the laptop and revert to the '**Accessing & Downloading Saved Data**' section to complete installation.

When necessary reverse the above steps for removal.

### **Overview**

BlokCam Office Link allows the data from your BlokCam to be captured in a site office for site and crane monitoring and surveillance. Your host computer could monitor and record data from multiple systems. BlokCam Office Link and software comes with many additional benefits and features including:

- Quick and easy to install;
- Take screen shots;
- Extract footage for training and investigation;
- Integrated 12dBi antenna;
- Designed for outdoor applications;
- 1km transmission distance;
- Rugged mounting bracket;
- IP66.

### **Installation**

#### **Foreword**

Office links are factory programmed and paired to a specific Repeater. Please seek advice from an authorised BlokCam ® dealer for further programming and pairing options.

The Office Link is powered over ethernet (POE) using the supplied POE Injector or a suitable network switch.

To access and download data via the Office Link, ensure the BlokCam ® system and components are installed correctly and fully operational. Ensure the front face of the Office Link is facing, and has a direct line of sight to the paired Repeater.

You will need a Laptop with VMS installed (Video Management Software), a Cat5e RJ45 Patch Cable of suitable length and basic networking and IT skills. Laptop/System recommendations and VMS are available from [www.blokcaml.com](http://www.blokcaml.com)

Pre-empt the position of the Office Link and consider:

- a. the adjacent point to point relationship;
  - b. mounting options;
  - c. cable length, route and distance to the host computer;
  - d. the dynamics of machine;
  - e. possible changes to the surroundings.
1. Use the adjustable steel band to mount the Office Link to a fixed and secure point. If the supplied brackets are not suitable please seek advice from an authorised BlokCam ® dealer.

## VC4 - V-Cam



### Overview

The Versatile-Cam is our hardwired option which gives you the ability to expand your BlokCam ® system to include additional Sensors. The build quality of the VC4 coupled with its non-intrusive size and mounting versatility means it can be deployed in seconds and used in a multitude of scenarios. Ideal for visual monitoring and data logging of the Hoist Drum, Luffing Drum, Slew Ring, Tail Swing and the Operators Cab.

- Quick and easy to install;
- Uses high powered neodymium magnets;
- The lens is auto-focus and always gives clear views;
- HD1080p Resolution;
- Durable all-weather design, manufactured to IP66;
- Available with audio sensor as the (VC4a).

### Installation

#### Foreword

V-Cam's are factory programmed with a specific IP Address and paired to a specific system. Please seek advice from an authorised BlokCam ® dealer for further programming and pairing options.

The V-Cam is powered over ethernet (POE) via a connection to a Processor POE Port (Ports 1 – 4).

The installation of two or more cameras will require the installation of a footswitch or similar control mechanism to select the desired camera/s in single or split screen mode.

Pre-empt the position of the V-Cam and consider:

- a. the sensor cable length and route;
- b. the distance to the Processor;
- c. the view from the intended position;
- d. the lanyard length and distance to a secure point;
- e. the orientation of the camera;
- f. the dynamics of the machine.

1. Magnetically mount the V-Cam to a clean and flat surface.
2. Choke a lanyard to the V-Cam and secure with a zip tie.
3. Attach the loose end of the Lanyard to a fixed and secure point. If necessary, fit and firmly tighten a Quick Link to secure.
4. Secure the cable from the V-Cam to the Processor using zip ties.

5. Connect the hardwired LAN Cable from the V-Cam to one of the Processor's POE Ports (Ports 1 – 4).
6. After start up, if required, re-position the sensor to achieve the desired view.

When necessary reverse the above steps for removal.

## VC4a - V-Cam (Audio)



### Overview

The VC4a is our hardwired camera with a built-in microphone. The build quality coupled with its non-intrusive size and mounting versatility means it can be deployed in seconds. The VC4a is most commonly used for audio-visual monitoring and data logging of the Operators Cab.

- Quick and easy to install;
- Uses high powered neodymium magnets;
- The lens is auto-focus and always gives clear views;
- HD1080p Resolution;
- Built-in microphone;
- PIR motion sensor;
- Bracket for wall and corner mount;
- Day & night with IR illumination.

### Installation

See VC4 - V-Cam Installation Instructions

## FS1 - Footswitch



### Overview

When using multiple cameras, the Footswitch provides the hands-free operation that a crane operator needs to flick between single and split screen mode.

- Quick and easy to install;
- IP67.

### Installation

Pre-empt the position of the switch and consider:


- a. the Footswitch cable length and route;
- b. the distance to the processor.

1. Place the switch in a suitable position for the operator.
2. Secure the cable from the Footswitch to the Processor using zip ties.
3. Plug the Footswitch into the Processor's Blue Multi Camera Switch Socket



When necessary reverse the above steps for removal.

## BP1 - Pendulum



### Overview

BP1 allows you to install your existing sensor to the boom tip of a crane. The pendulum allows the sensor to pivot and focus on the hook block, load and surrounding area regardless of the angle of the jib.

### Installation

#### Foreword


Some assembly required, Installation of the Pendulum requires the use of medium strength thread lock and a 24mm spanner/wrench.

1. Follow the instruction on the thread lock.
2. Apply thread lock to the Pendulum thread.
3. Screw the Pendulum thread into the rear, top recess of the Sensor, as pictured below and tighten using a spanner/wrench.




4. Allow the thread lock to dry thoroughly prior to use.
5. Install and secure the sensor as instructed on page 11.
6. Ensure the sensor cable does not limit or dictate the rotation of the Pendulum.

## BM1 - BlokMag



The above images show the Transmitter BlokMag® (BM1-X) configured for installation on a cylindrical surface.

The below images show the Transmitter BlokMag® (BM1-X) configured for installation on a spherical surface.



## Overview

Attach your crane camera system to a curved surface. Flat, spherical, cylindrical, narrow, short or tall, our modular BlokMag® system allows flat surfaces to mate with curved surfaces flawlessly. Mount your Transmitter, Sensor and/or Battery to the matching BlokMag® magnetically, or if preferred, use the countersunk holes on rear of the Bracket Plate using countersunk fixings.

## Assembly


### Foreword

Some assembly required. BlokMag's® are dispatched partially assembled to improve modularity and increase installation options.

Each Bracket Plate comes with four Link Arms and associated fixings. Link Arms are factory assembled and retained with high strength thread lock. Each Link Arm includes :

- 1 x Mounting link
- 3 x Mid Link's, complete with magnets
- 1 x End Link, complete with magnet

Multiple threaded holes on the Bracket Plate allows the Link Arms to be installed at increments of 22.5-degree angles. You will need a 3mm hex key to fit the Link Arms to the Bracket Plate.



1. Position the 4 x Link Arms on the countersunk, rear face of the Bracket Plate to achieve the most suitable configuration.
2. Place an M5 spring washer (supplied) onto an M5 Button Head Socket Bolt (supplied).
3. Insert the bolt and spring washer into counterbored hole in the Mounting Link and screw to the Bracket Plate.
4. Repeat steps 2 and 3 until each Mounting Link and corresponding Link Arm has been fitted with two fixings.
5. Use a 3mm Hex Key (not supplied) to tighten the fixings and secure the Mounting Links to the Bracket Plate.
6. If desired, use countersunk fixings (not supplied) and medium strength thread lock (not supplied) to fix the Transmitter, Sensor and/or Battery to the matching BlokMag ®.

## Installation

Pre-empt the position of the BlokMag ® and consider:

- a. the installation requirements of the mating Transmitter, Sensor and/or Battery;
  - b. the lanyard length and distance to a secure point.
1. Magnetically mount the BlokMag ® to a clean surface.
  2. Ensure the assembly and configuration of the link arms are suitable and adjust if necessary.
  3. Check each link arm is taught and correctly magnetised to the curved surface.
  4. Fit Quick Link to BlokMag ®.
  5. Choke and secure a lanyard to fixed and secure point.
  6. Attach the loose end of lanyard to the Quick Link.
  7. Firmly tighten the Quick Link.
  8. Refer to the installation guide for the mating Transmitter, Sensor and/or Battery.

When necessary reverse the above steps for removal.

## Wireless Programming

### Foreword

In Wi-Fi networking, a point-to-point wireless bridge lets users wirelessly connect two or more locations together. This bridge connects two or more locations to share data across the network.

BlokCam® transceivers operate within the 5GHz band. For best results ensure a direct line of sight between all wireless transceivers and antennas.

Frequency selection and transmit power may vary. Please refer to regional regulations, guidelines and authorities to ensure legal operation.

You will need a Laptop with BlokView® Software installed, a Cat5e RJ45 Patch Cable of suitable length and basic networking and IT skills. Laptop/System recommendations and Software are available from [www.blokcaml.com](http://www.blokcaml.com)

To program or modify the wireless settings, ensure the BlokCam® system and components are installed and/or connected as per the installation guide.

With the correct credentials, the transceivers can be programmed using a wired and/or wireless connection. When programming using a wireless connection, take note of the changes and new credentials. If wireless connectivity is not possible due to unknown and/or incorrect credentials, please revert to a wired connection.

Transmitters can only be programmed wirelessly. Incorrect programming may lead to unknown credentials and loss of connectivity. In this situation the Transmitter will need to be returned to an authorised BlokCam® dealer to be reprogrammed and resealed.

Repeaters and Office Links can be programmed using a wired and/or wireless connection.


Transmitters and Office Links are usually configured as a 'Station WDS'. Repeaters are usually configured as an 'Access Point WDS'.

### Unit Discovery


1. Connect to the network as detailed on page 15.
2. Open the BlokView® Software application.




3. Type 'password' into the password box.




4. Select 'Log In'.




5. If prompted 'refresh IP address'.
6. Select 'Discover Units' in the top left of the application.




7. When the search is complete select ALL visible units and 'Add Selected Units to Site'



8. Select 'Replace'.




9. Select 'No'.




## Accessing the Wireless Configuration Settings

1. Right Click on the desired connection.




2. Select 'Quick Config' in the pop-up window.
3. Type 'admin' in to the 'Login' box.




4. Obtain the password from an authorised BlokCam ® dealer.

5. Type the precured password into the 'Password' box.



6. Select 'Login to Unit'.
7. The Quick Config window will open allowing several changes to be made to the configuration of the chosen device.





## Changing the Channel

### Foreword

The Access Point controls the channel selection. It is not possible to change the channel through the configuration of a Station.

1. Select the desired RF Channel from the dropdown menu using the drop-down arrow or select the 'Auto Select Channel'.

192.168.0.193 Quick Config

Config Items

RF Channel: 5180 MHz

☒ Auto Select Channel

☐ Access Point ☐ Station

☐ Station WDS ☒ Access Point WDS ☐ Hide SSID

SSID: example

Security Settings

☒ WPA2 PSK AES ☐ None ☐ Leave Current Settings

Passphrase: example

Unit ID

IP Address: 192.168.0.193  
Net Mask: 255.255.255.0  
Unit Name: AP

Advanced Settings

Link Distance: 1000 Metres

Guard Interval: Short Channel BW: 20/40 MHz

Antenna Gain: 0

☐ Outdoor Channels ☐ Auto Adjust Slot and ACK Timing

Set Config

2. If no further programming is required, select 'Set Config'.
3. Allow the transceiver to reboot.
4. Test the system and if required, change the channel again.

## Changing the SSID, Passphrase & IP Address

### Foreword

When programming multiple transceivers from a single point of access, such as the Processor, always start by reprogramming the last in line connection.

The SSID is case sensitive and must be identical across all paired units.

The Passphrase is case sensitive and must be identical across all paired units.

Changing the IP Address may result in loss of communication through the BlokView Software, and the need to rediscover units.

An IPv4 IP Address is made up of 4 Octets. The first, second and third Octet must be identical for connectivity across all paired units. The forth Octet must be unique to avoid conflicting IP Addresses.

IPv4	1 <sup>st</sup> Octet	2 <sup>nd</sup> Octet	3 <sup>rd</sup> Octet	4 <sup>th</sup> Octet
Laptop	192	168	0	189
Camera	192	168	0	191
Transmitter	192	168	0	192
1 <sup>st</sup> Repeater	192	168	0	193
2 <sup>nd</sup> Repeater	192	168	0	194
Office Link	192	168	0	195

1. Type your chosen SSID in to the 'SSID' box.
2. Type your chosen Passphrase in to the 'Passphrase' box.
3. Type your chosen IP Address in to the 'IP Address' box.

192.168.0.193 Quick Config

Config Items

RF Channel: 5180 MHz

☐ Auto Select Channel

☐ Access Point ☒ Station

☐ Station WDS ☒ Access Point WDS ☐ Hide SSID

SSID: example

Security Settings

☒ WPA2 PSK AES ☐ None ☐ Leave Current Settings

Passphrase: example

Unit ID

IP Address: 192.168.0.193  
Net Mask: 255.255.255.0  
Unit Name: AP

Advanced Settings

Link Distance: 1000 Metres

Guard Interval: Short Channel BW: 20/40 MHz

Antenna Gain: 0

☐ Outdoor Channels ☐ Auto Adjust Slot and ACK Timing

Set Config

4. Select 'Set Config'.
5. Allow the transceiver to reboot.
6. Continue programming until all devices are as required.
7. Test the system and change the settings if required.

## Fault Finding Guide

### Foreword

The fault-finding guide is written with the assumption that installation has been carried out in accordance with the installation guide.

### Transmitter and Repeater LED Key

- LED – On
- ◐ LED – Consistent Flashing
- LED – Off
- ◑ LED – Inconstant Flashing


### Transmitter and Wired Repeater LED Indicator Table

		Signal Strength ≥				Status	Description	Wireless Signal Strength	Solution
Power	Data	25%	50%	75%	100%				
●	◐	●	●	●	●	Normal		100%	N/A
●	◐	●	●	●	○	Normal		75% to 99%	N/A
●	◐	●	●	○	○	Normal		50% to 74%	N/A
●	◐	●	○	○	○	Normal		25% to 49%	N/A
●	◑	○	○	○	○	Fault	Transceiver - Poor or no wireless signal	Less than 25%	Refer to section 1.0
○	○	○	○	○	○	Fault	Transceiver - No power/lights	0%	Refer to section 1.1
●	○	●	●	●	●	Fault	Transceiver - No data input/output	100%	Refer to section 1.3
●	○	●	●	●	○	Fault	Transceiver - No data input/output	75% to 99%	Refer to section 1.3
●	○	●	●	○	○	Fault	Transceiver - No data input/output	50% to 74%	Refer to section 1.3
●	○	●	○	○	○	Fault	Transceiver - No data input/output	25% to 49%	Refer to section 1.3
●	○	○	○	○	○	Fault	Transceiver - No data input/output	Less than 25%	Refer to section 1.3
●	◑	○	○	○	◐	Fault	WiFi PCB memory loss. PCB in diagnostics mode.	0%	Replace WiFi PCB.


## Wireless Repeater LED Indicator Table

Signal Strength ≥						Status	Description	Wireless Signal Strength	Solution
Power	Data	25%	50%	75%	100%				
●	○	●	●	●	●	Normal		100%	N/A
●	○	●	●	●	○	Normal		75% to 99%	N/A
●	○	●	●	○	○	Normal		50% to 74%	N/A
●	○	●	○	○	○	Normal		25% to 49%	N/A
●	○	○	○	○	○	Fault	Transceiver - Poor or no wireless signal	Less than 25%	Refer to section 1.0
○	○	○	○	○	○	Fault	Transceiver - No power/lights	0%	Refer to section 1.1
●	●	○	○	○	●	Fault	WiFi PCB memory loss. PCB in diagnostics mode.	0%	Replace WiFi PCB.

## WiFi PCB LED Key



## AV PCB LED Key



































































































## AV PCB LED Indicator Table

Power LED	Indication	Solution
Green	Normal operation.	N/A
Amber	Flashes green/amber during firmware upgrade.	Refer to section 1.3
Status LED	Indication	Solution
Green	Steady green for normal operation.	N/A
Amber	Steady during start-up. Flashes when restoring settings.	Refer to section 1.3
Red	Firmware upgrade failure.	Refer to section 1.3
Network LED	Indication	Solution
Green	Steady for connection to a 100 Mbit/s network. Flashes for network activity.	N/A
Amber	Steady for connection to a 10 Mbit/s network. Flashes for network activity.	Refer to section 1.3
Unlit	No network connection.	Refer to section 1.3

## Processor LED Key


●	LED – On	○	LED – Off
◐	LED – Consistent Flashing	◑	LED – Inconstant Flashing

**Processor LED Indicator Table**


<b>Normal Operation.</b> PoE Port 1 in use. 	<div style="text-align: center;">PoE Ports</div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">           PoE MAX ○         </div> <div style="display: flex; align-items: center;">     </div> <div style="margin-left: 10px;">           PoE Status            ○   ○            5   6            D         </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;">     </div> <div style="display: flex; align-items: center; margin-top: 10px;">        </div>
<b>Normal Operation.</b> PoE Port 1 & 2 in use. 	<div style="text-align: center;">PoE Ports</div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">           PoE MAX ○         </div> <div style="display: flex; align-items: center;">     </div> <div style="margin-left: 10px;">           PoE Status            ○   ○            5   6            D         </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;">     </div> <div style="display: flex; align-items: center; margin-top: 10px;">        </div>
<b>Faulty Operation.</b> No power/lights on PoE injector. Refer to section 1.2 	<div style="text-align: center;">PoE Ports</div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">           PoE MAX ○         </div> <div style="display: flex; align-items: center;">     </div> <div style="margin-left: 10px;">           PoE Status            ○   ○            5   6            D         </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;">     </div> <div style="display: flex; align-items: center; margin-top: 10px;">        </div>
<b>Faulty Operation.</b> PoE Port 1 in use. Port 1: No PoE to load Refer to section 1.2 	<div style="text-align: center;">PoE Ports</div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">           PoE MAX ○         </div> <div style="display: flex; align-items: center;">     </div> <div style="margin-left: 10px;">           PoE Status            ○   ○            5   6            D         </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;">     </div> <div style="display: flex; align-items: center; margin-top: 10px;">        </div>
<b>Faulty Operation.</b> PoE Port 1 in use. Port 1: PoE to the load. No data transfer from source to PoE Injector. Refer to section 1.2 	<div style="text-align: center;">PoE Ports</div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">           PoE MAX ○         </div> <div style="display: flex; align-items: center;">     </div> <div style="margin-left: 10px;">           PoE Status            ○   ○            5   6            D         </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;">     </div> <div style="display: flex; align-items: center; margin-top: 10px;">        </div>
<b>Faulty Operation.</b> PoE Port 1 in use. No 'D' LED. No data transfer from PoE injector to Processor PCB. Refer to section 1.4 	<div style="text-align: center;">PoE Ports</div> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">           PoE MAX ○         </div> <div style="display: flex; align-items: center;">     </div> <div style="margin-left: 10px;">           PoE Status            ○   ○            5   6            D         </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;">     </div> <div style="display: flex; align-items: center; margin-top: 10px;">        </div>

Transceiver - Poor or no wireless signal.	→	Refer to section 1.0
Transceiver - No power/lights on.	→	Refer to section 1.1
Transceiver - No power/lights (Continued).	→	Refer to section 1.2
Transceiver - No data input/output.	→	Refer to section 1.3
Processor - No power/lights.	→	Refer to section 1.2
Processor - No port related lights.	→	Refer to section 1.2
Processor – No port related Link Act light.	→	Refer to section 1.2
Processor – No 'D' LED.	→	Refer to section 1.4
Battery charging issue.	→	Refer to section 1.5
Monitor - No power/ lights.	→	Refer to section 1.6
Monitor - 'No Video' message.	→	Refer to section 1.7
Monitor - Black screen.	→	Refer to section 1.8
Monitor - Blue screen with 'no signal' message.	→	Refer to section 1.9
Monitor - On screen image freezing/frozen.	→	Cross reference parts to related LED indicator table.
Battery Schematic.	→	Refer to section 2.0
Charging Station Schematic.	→	Refer to section 2.1
Processor Schematic.	→	Refer to section 2.2
Repeater Schematic.	→	Refer to section 2.3
Transmitter Schematic.	→	Refer to section 2.4

## Section 1.0 - Transceiver - Poor or no wireless signal, less than 25%




## Section 1.1 - Transceiver - No power/lights, Flow Chart







## Section 1.2 - Transceiver - No power/lights (Continued), Flow Chart




### Section 1.3 - Transceiver - No data input/output, Flow Charts




## Section 1.4 - Processor - No 'D' LED, Flow Chart




## Section 1.5 – Battery charging issues, Flow Chart




## Section 1.6 - Monitor - No power/lights, Flow Chart




## Section 1.7 - Monitor - 'No video' message, Flow Chart



## Section 1.8 - Monitor - Black Screen, Flow Chart




### Section 1.9 - Monitor - Blue screen with 'no signal' message, Flow Chart





## Section 2.0 – Battery Schematic



### 19.2V 4.2Ah Cell Pack

- Voltage Negative (Black)  
+ Voltage Positive (Red)  
NTC Thermistor (White)


### Low Voltage Cut Off PCB (LVCOP)

To prevent over discharge, the LVCOP analyses the condition of the cell pack.

The LVCOP will cut power to the load when the cell pack voltage drops below 16Vdc.

The charging process will reset the LVCOP when voltage input reaches 22Vdc or higher.


## Section 2.1 – Charging Station Schematic




### Charging Station PCB

UT- Voltage Negative  
UT+ Voltage Positive  
NTC+ Thermistor Positive


## Section 2.2 – Processor Schematic



## Section 2.3 - Repeater Schematic



## Section 2.4 - Transmitter Schematic





BlokCam Ltd  
Unit 5 Sidings Court  
Priory Park East  
Hull  
East Yorkshire  
HU4 7DY  
United Kingdom

+44 1482 351546  
uk@blokcam.com

