

Unit 5 Sidings Court, Priory Park East, Hull, HU4 7DY Tel: +44 (0) 1482 351546 Fax: +44 (0) 1482 351091 www.blokcam.com info@blokcam.com

## **Battery Charging Instructions – Model X**

The BlokCam camera system runs on a non-hazardous battery, providing approximately 12 hours of use under normal operating conditions. Certain operating conditions will decrease the standard runtime of the battery, including extreme hot or cold temperatures. The battery takes approximately 5 hours to fully charge. The charger and any spare batteries should be kept in a dry environment such as a job trailer, site office or similar environment. BlokCam recommends swapping and charging the battery at the beginning of every shift.

- Disconnect the power cable from the Battery.

  Depress the lever on the Connector.

  Pull Connector away from Battery Socket.
- Disconnect the Quick Link from the Battery
  Fully unscrew the fastening and remove quick link from battery
- Remove the Magnetically Mounted Battery
  With a firm grip, remove the battery by rolling the housing off the face of the Hook Block
- Prior to connecting the Charger to the Battery
  Please ensure the charger is disconnected from the mains supply or switched off
- Connecting the Charger to the Battery
  Push the connector on the charger over the battery socket until the connector "Clicks"
- Power up the Charger
  Connect the charger to the mains supply and/or switch the mains supply on
- 7 Checking the Charger
  Use the LED Indicator and instructions on the underside of charger to check charge condition/status.













